

Instruction and Safety Manual

Portable Shooting Bench Swivel

Model: PSBS-092 [Maximum Weight Limit - 300 LBS]

www.candsglobal.us.com

Please inspect the shipping carton for damage or evidence that it may have been opened before you received it. Then inspect your product carefully. If for any reason you are not satisfied with the product, do not use it until the problem is corrected. You must check and tighten all bolts before each use.



CARTON CONTENTS:

A	1 Camo Table Top Cover	Part # TTC-09
B	1 Table Top Frame	Part # TTF-09
C	1 Shooting Rest	Part # SR-09
D	1 Swivel Post Assembly	Part # 0921
E	1 Seat Assembly	Part # 0922
F	2 Camo Backpack Straps	Part # 1020
G	3 Table Leg	Part # 0923
H	2 Strap Bracket	Part # 0924
	3 8mm x 1-3/4 inch bolt	Part # 1048
	1 8mm x 2-1/4 inch bolt	Part # 1051
	1 8mm x 2-3/4 inch bolt	Part # 1008
	6 8mm locknut	Part # 1006
	2 6mm x 1/2 inch bolt	Part # 1090
	2 Plastic Washer	Part # 1038
	3 Long Quick Clips	Part # 1068
	1 Adjustment Bolt	Part # 1067

WARNING

It is recommended that you lubricate all hardware annually or as needed. It is recommended that you replace all hardware (locknuts, wingnuts, and/or bolts) on every three years.

ALWAYS Test and practice using this product until you are comfortable with it.

REPLACEMENTS


When calling for parts, always give the following information to the customer service representative:

- 1) Proof of Purchase
- 2) Model Number
- 3) Part Description and Part Number
- 4) Quantity
- 5) Reason for Replacement

Hours of Operation: 9am-4:30pm Central Time
(309) 676-7930

ASSEMBLY

1. Slide table post onto arm on table top frame and bolt using one 8mm x 2-3/4 inch bolt, two plastic washers and one 8mm locknut. Tighten bolt securely and hand tighten adjustment bolt.



2. Bolt first table leg to post using one 8mm x 1-3/4 inch bolt and one 8mm locknut on the outer hole. Insert one quick clip into the inner hole to keep leg stationary. Repeat for other two legs. Tighten bolts securely.



3. Bolt seat assembly to table post in desired height using one 8mm x 2-1/4 inch bolt and one 8mm locknut. Tighten bolt securely. Attach backpack straps, slip on table top cover and screw in shooting rest.




INSTRUCTIONS

1. Loosen adjustment bolt, pull post away from table top, and lay post across bottom of table top. Post will still be attached to table top.




2. Remove quick clips from table post.



3. Fold legs up to table top. Fold seat up also. Re-insert quick clips into table post.



4. Clip strap around folded legs and seat to secure it to table top. With backpack straps on the outside of the legs, table is now ready to be carried.



Reverse this process to setup.

Images used are for demonstration purposes only and may not depict the actual product.